

v-stays rods fitting into AUWÄRTER

082754100	0827.541.00
082755100	0827.551.00

v-stays rods fitting into DAF

0080521	0 080 521
0082678	0 082 678
0649819	0 649 819
0658102	0 658 102
1361651	1 361 651
1361652	1 361 652
1368270	1 368 270
1390932	1 390 932
1617096	1 617 096
1620436	1 620 436
1620437	1 620 437
1793875	1 793 875
1793876	1 793 876
1793877	1 793 877
1817808	1 817 808

v-stays rods fitting into EVOBUS

8226296000	8.226.296.000
8226351000	8.226.351.000
8226352000	8.226.352.000

v-stays rods fitting into IVECO

04716271	0471 6271
08137026	0813 7026
41002770	4100 2770
41009665	4100 9665
41021071	4102 1071
41022092	4102 2092
41028598	4102 8598
41028599	4102 8599
41028600	4102 8600
41029665	4102 9665
41033479	4103 3479
41034479	4103 4479
41035950	4103 5950
41042050	4104 2050
41042092	4104 2092
41042093	4104 2093
41042093	4104 2093
41218621	4121 8621
41272427	4127 2427
41272706	4127 2706
41296730	4129 6730
4463925	446 3925
4716271	471 6271
4716799	471 6799
4855237	485 5237
4855237	485 5237
4865483	486 5483

500340451	5 0034 0451
8137026	813 7026
98472468	9847 2468
98487790	9848 7790
99484068	9948 4068

v-stays rods fitting into KÄSSBOHRER	
8226296000	8.226.296.000
8226351000	8.226.351.000
8226352000	8.226.352.000

v-stays rods fitting into LEMFÖRDER	
11396	11396
1143002	11430 02
1146502	11465 02
1160601	11606 01
1171501	11715 01
11737	11737
1176002	11760 02
1181901	11819 01
11823	11823
11827	11827
11940	11940
11943	11943
12858	12858
1285901	12859 01
12928	12928
13573	13573
18478	18478
1959901	19599 01
19630	19630
19739	19739
1977701	19777 01
2039901	20399 01
2065701	20657 01
2101301	21013 01
2116801	21168 01
21438	21438
2147401	21474 01
21547	21547
22302	22302
2270501	22705 01
2271501	22715 01
23042	23042
23046	23046
23047	23047
23048	23048
23049	23049
23051	23051
23052	23052
23054	23054
23055	23055
23056	23056
23058	23058
23059	23059
2306001	23060 01
23061	23061

2306201	23062 01
23063	23063
23064	23064
2306501	23065 01
2306902	23069 02
23070	23070
23072	23072
2307501	23075 01
2307801	23078 01
2307901	23079 01
2325201	23252 01
2370301	23703 01
23706	23706
23709	23709
23710	23710
2480601	24806 01
25043	25043
2511601	25116 01
25164	25164
25168	25168
2521001	25210 01
2521101	25211 01
2531401	25314 01
2561201	25612 01
26029	26029
2603101	26031 01
2605301	26053 01
2605801	26058 01
2606201	26062 01
2664701	26647 01
2669101	26691 01
2680501	26805 01
2681301	26813 01
2724201	27242 01
2732201	27322 01
2770901	27709 01
27761	27761
27762	27762
2776301	27763 01
2776401	27764 01
27765	27765
27766	27766
27767	27767
2932401	29324 01
2938701	29387 01
2965201	29652 01
2983601	29836 01
3041601	30416 01
3072801	30728 01
3075201	30752 01
3116801	31168 01
3136701	31367 01
3136801	31368 01
3188701	31887 01
3373601	33736 01
3373701	33737 01
3373801	33738 01
3436201	34362 01
3436801	34368 01
3458601	34586 01
3465501	34655 01

3498001	34980 01
3500901	35009 01

v-stays rods fitting into MAN	
81432706027	81.43270.6027
81432706029	81.43270.6029
81432706030	81.43270.6030
81432706033	81.43270.6033
81432706034	81.43270.6034
81432706036	81.43270.6036
81432706039	81.43270.6039
81432706041	81.43270.6041
81432706046	81.43270.6046
81432706050	81.43270.6050
81432706053	81.43270.6053
81432706054	81.43270.6054
81432706055	81.43270.6055
81432706056	81.43270.6056
81432706057	81.43270.6057
81432706067	81.43270.6067
81432706074	81.43270.6074
81432706075	81.43270.6075
81432706076	81.43270.6076
81432706077	81.43270.6077
81432706078	81.43270.6078
81432706081	81.43270.6081
81432706082	81.43270.6082
81432706087	81.43270.6087
81432706088	81.43270.6088
81432706093	81.43270.6093
81432706094	81.43270.6094
81432706095	81.43270.6095
81432706096	81.43270.6096
81432706097	81.43270.6097
81432706102	81.43270.6102
81432706103	81.43270.6103
81432706106	81.43270.6106
81432706107	81.43270.6107
81432706108	81.43270.6108
81432706112	81.43270.6112
81432706113	81.43270.6113
81432706114	81.43270.6114
81432706115	81.43270.6115
81432706116	81.43270.6116
81432706117	81.43270.6117
81432706129	81.43270.6129
81432706130	81.43270.6130
81432706131	81.43270.6131
81432706136	81.43270.6136
81432706137	81.43270.6137
81432706140	81.43270.6140
81432706145	81.43270.6145
81432706146	81.43270.6146
81432706155	81.43270.6155
81432709034	81.43270.9034
81432709053	81.43270.9053
81432709054	81.43270.9054
81432709056	81.43270.9056
81432709076	81.43270.9076

81432709077	81.43270.9077
81432709078	81.43270.9078
81432709096	81.43270.9096
81433156036	81.43315.6036
81433156037	81.43315.6037
81433156038	81.43315.6038
82432701601	82.43270.1601
82432706005	82.43270.6005
82432706007	82.43270.6007
83432706000	83.43270.6000
85432706001	85.43270.6001
88432706801	88.43270.6801

v-stays rods fitting into MERCEDES-BENZ	
0005860632	000 586 06 32
3563301410	356 330 14 10
3563301510	356 330 15 10
3563331304	356 333 13 04
3633500205	363 350 02 05
3833500105	383 350 01 05
3833500105	383 350 01 05
3933505205	393 350 52 05
3933505205	393 350 52 05
3933505305	393 350 53 05
3933505305	393 350 53 05
3933505404	393 350 54 04
3933505405	393 350 54 05
3933505505	393 350 55 05
3933505605	393 350 56 05
3935505405	393 550 54 05
3963500005	396 350 00 05
4933301107	493 330 11 07
6133300010	613 330 00 10
6133300110	613 330 01 10
6133330104	613 333 01 04
6273500105	627 350 01 05
6523500005	652 350 00 05
6533500005	653 350 00 05
6533500105	653 350 01 05
6533500105	653 350 01 05
6533500205	653 350 02 05
6533500205	653 350 02 05
6533500305	653 350 03 05
6533500405	653 350 04 05
6533530005	653 353 00 05
6543500005	654 350 00 05
6543500105	654 350 01 05
6543500305	654 350 03 05
6553500305	655 350 03 05
6563500005	656 350 00 05
6583500005	658 350 00 05
6583500005	658 350 00 05
6583500105	658 350 01 05
6583500205	658 350 02 05
6993500305	699 350 03 05
9423500105	942 350 01 05
9423500205	942 350 02 05
9423500505	942 350 05 05
9423500805	942 350 08 05

9423501005	942 350 10 05
9423501105	942 350 11 05
9423501205	942 350 12 05
9423501505	942 350 15 05
9423501605	942 350 16 05
9443500005	944 350 00 05
9443500305	944 350 03 05
9443500405	944 350 04 05
9443500505	944 350 05 05
9443500605	944 350 06 05
9473500105	947 350 01 05
9473500305	947 350 03 05
9473500405	947 350 04 05
9473500705	947 350 07 05
9473500905	947 350 09 05
9473501005	947 350 10 05
9483500405	948 350 04 05
9483500905	948 350 09 05
9483501105	948 350 11 05
9483501705	948 350 17 05
9483502105	948 350 21 05
9483502205	948 350 22 05
9483502305	948 350 23 05
9483502705	948 350 27 05
9483502805	948 350 28 05
9483502905	948 350 29 05
9483503005	948 350 30 05
9743500005	974 350 00 05
9743500405	974 350 04 05
9743500505	974 350 05 05

v-stays rods fitting into NEOPLAN

082750900	08.275.09.00
11013443	1101 3443
11015863	1101-5863
N1011015863	N1.01101-5863

v-stays rods fitting into R.V.I. RENAULT

5000791224	50 00 791 224
5006172093	50 06 172 093
5010347868	50 10 347 868
7420741703	74 20 741 703
7420829503	74 20 829 503
7421295227	74 21 295 227

v-stays rods fitting into SCANIA

0445631	0 445 631
0445632	0 445 632
1440028	1 440 028
1722582	1 722 582
416524	416 524
417261	417 261
418038	418 038
445631	445 631
445632	445 632

489986	489 986
--------	---------

v-stays rods fitting into VAN HOOL

10626205	10626205
----------	----------

v-stays rods fitting into VOLVO

1076639	1 076 639
1080690	1 080 690
1094466	1 094 466
1194631	1 194 631
119806011623	119 806 011 623
1576952	1 576 952
1590068	1 590 068
1592993	1 592 993
1605244	1 605 244
1606200	1 606 200
1606385	1 606 385
1606552	1 606 552
1628483	1 628 483
1628485	1 628 485
20367004	20 367 004
20382314	20 382 314
20428251	20 428 251
20491771	20 491 771
20502944	20 502 944
20507262	20 507 262
20556488	20 556 488
20556490	20 556 490
20556491	20 556 491
20556492	20 556 492
20556493	20 556 493
20556586	20 556 586
20556588	20 556 588
20556590	20 556 590
20556608	20 556 608
20589061	20 589 061
20703338	20 703 338
20741695	20 741 695
20741703	20 741 703
20829503	20 829 503
21295227	21 295 227
3172829	3 172 829
3173289	3 173 289
3173290	3 173 290
3173291	3 173 291
3173292	3 173 292
3173293	3 173 293
3173294	3 173 294
3173295	3 173 295
3173297	3 173 297
3173829	3 173 829
8073569	8 073 569
8156991	8 156 991
8156994	8 156 994